



Instructions for Hidden Brackets Installation

- ✓ Bracket must be mounted facing upwards. The bracket has a 5mm incline to fit over shelf
- ✓ Hidden Brackets must be mounted directly on to timber.
- ✓ Remove any gib from the timber stud before mounting
- ✓ Place the bracket in the position required
- ✓ Fix bracket to stud with strong screws making sure bracket is very secure.
- ✓ Suggest using at least a 50mm long screw
- ✓ Drill into shelf side where bracket is to be mounted.
- ✓ Drill hole to be 10 mm X 122 mm deep
- ✓ Place shelf over bracket making sure secure

We accept no responsibility to any damage resulting in your actions. At time of despatch your brackets will have been tested.